



MODERN PLAYER TELECASTER® PLUS (0241102XXX)

PARTS LAYOUT



MODERN PLAYER TELECASTER® PLUS (0241102XXX)

WIRING ASSEMBLY



MODERN PLAYER TELECASTER® PLUS (0241102XXX)

SWITCH AND CONTROL FUNCTION

SWITCH FUNCTIONS					
MINI TOGGLE DOWN					
5	4	3	2	1	5-WAY SWITCH POSITION
					NECK PICKUP
					MIDDLE PICKUP
					BRIDGE PICKUP
					BRIDGE PICKUP
					NECK PICKUP
					MIDDLE PICKUP
					BRIDGE PICKUP
					PICKUP IS ON
					PICKUP IS OFF
INDICATES POSITION OF THE 5-WAY SWITCH					
MINI TOGGLE DOWN			MINI TOGGLE UP		

